

| REPORT DOCUMENTATION PAGE   |   |  | Form Approved<br>OMB No. 0704-0188  |  |
|---|---|--|---|--|
| <small>Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503.</small> |   |  |   |  |
| 1. AGENCY USE ONLY (Leave blank)  |   | 2. REPORT DATE<br>1999 June 28                             | 3. REPORT TYPE AND DATES COVERED<br>Final 1994 December 22-1996 December 21 |  |
| 4. TITLE AND SUBTITLE<br>High-Tc Superconducting Multilevel Materials and Device Development and Device Physics   |   |  | 5. FUNDING NUMBERS<br><br>C-N00014-95-C-0056                                |  |
| 6. AUTHOR(S)<br>Roger Koch  |   |  |   |  |
| 7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES)<br>IBM Thomas J. Watson Research Center<br>P.O. Box 218<br>Yorktown Heights, NY 10598  |   |  | 8. PERFORMING ORGANIZATION<br>REPORT NUMBER<br>1F                           |  |
| 9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)<br>Office of Naval Research<br>800 North Quincy Street<br>Arlington, VA 22217   |   |  | 10. SPONSORING/MONITORING<br>AGENCY REPORT NUMBER                           |  |
| 11. SUPPLEMENTARY NOTES   |   |  |   |  |
| 12a. DISTRIBUTION/AVAILABILITY STATEMENT<br><br>Unclassified/Unlimited  |   |  | 12b. DISTRIBUTION CODE  |  |
| 13. ABSTRACT (Maximum 200 words)<br>A two-year research effort on Navy applications of High-Tc SQUIDS is described. Over the course of the contract, we reviewed materials research and operation of SQUIDS in a small magnetic field. We examined some applications of SQUIDS, including Naval Gradiometers, Biomagnetometers and Scanning SQUID microscopes.  |   |  |   |  |
| 14. SUBJECT TERMS<br>High-Temperature Superconductivity; Superconductivity<br>Quantum Interface Devices (SQUIDS)  |   |  | 15. NUMBER OF PAGES<br>33   |  |
|   |   |  | 16. PRICE CODE  |  |
| 17. SECURITY CLASSIFICATION<br>OF REPORT<br>Unclassified  | 18. SECURITY CLASSIFICATION<br>OF THIS PAGE<br>Unclassified | 19. SECURITY CLASSIFICATION<br>OF ABSTRACT<br>Unclassified | 20. LIMITATION OF ABSTRACT<br>Unlimited                                     |  |

NSN 7540-01-280-5500

Standard Form 298 (Rev. 2-89)  
Prescribed by ANSI Std. Z39-18  
298-102

DTIC QUALITY INSPECTED 4

**Report IBM N00014-95-C-0056 Final**

**High-Tc Superconducting Multilevel Materials and Device Development and  
Device Physics**

**Contract N00014-95-C-0056**

**PROBLEM TO SOLVE:  
DEVELOP NAVY APPLICATIONS OF HIGH-TC SQUIDS**

**OUR PART OF SOLUTION:  
UNSHIELDED/MOBILE OPERATION OF SQUIDS**

|                         |                             |
|-------------------------|-----------------------------|
| <b>Roger Koch</b>       | <b>IBM Research</b>         |
| <b>Frank Milliken</b>   | <b>Yorktown Heights, NY</b> |
| <b>Jim Rozen</b>        |                             |
| <b>Steve Brown</b>      |                             |
| <b>Pieter Woeltgens</b> |                             |

**Review materials research**

**Review operation of SQUIDS in a small magnetic field**

**Examine some applications of SQUIDS**

- 1. Naval Gradiometers**
- 2. Biomagnetometers**
- 3. Scanning SQUID microscopes**

**28 June 1999**

**Final Report Covering December 22, 1994 to December 21, 1996**

**Reproduction in whole, or in part, is permitted for any purpose of the  
United States Government**

**Prepared for:**

**Office of Naval Research  
Department of the Navy  
800 North Quincy Street  
Arlington, VA 22217**

## SQUID APPLICATIONS:

Successful in a "marketplace":

1. Brain biomagnetometer
2. SQUID susceptometer
3. SQUID microscope
4. Scientific applications
5. Rock magnetometer

OPERATE WHILE  
SHIELDED AND/OR  
STATIONARY

Technically successful:

1. Geophysical sensors (e.g. MT)
2. Radiation receivers

OPERATE WHILE  
STATIONARY &  
"AWAY FROM IT ALL

Technically still very difficult:

1. Heart biomagnetometers
2. Navy submarine or mine detection
3. Most NDE applications


OPERATE WHILE/  
AFTER MOVING  
AND WHILE  
"POORLY" SHIELDED

## USING SQUIDS IN UNSHIELDED ENVIROMENTS:

If High- $T_c$  SQUIDS are to become economically viable products (that survive without government funding) we need to learn how to operate them outside of  $B=0$ ,  $\Delta B=0$ ,  $\Delta T=0$ , and RFI and magnetically shielded enclosures:

|                   |  |
|-------------------|--|
| $B = B_{EARTH}$   | use narrow lines and/or holes,<br>fluxdams, heaters, laser zappers |
| $\Delta B \neq 0$ | TSG active cancellation, fluxdams,<br>good quality materials       |
| $\Delta T \neq 0$ | fluxdams, good quality materials                                   |
| RFI $\neq 0$      | high bandwidth electronics   |
| Magnetic noise    | magnetic references, gradiometers                                  |


OR DO WHAT IS DONE IN LOW- $T_c$ ....  
superconducting shields and wires



What we really need is the usability and cost of a fluxgate!


FLUXGATE  $\rightarrow 2 \text{ pT}/\sqrt{\text{Hz}}$  @  $1 \text{ Hz}$  — \$ 1,000  
 HIGH- $T_c$  SQUID  $200 \text{ fT}/\sqrt{\text{Hz}}$  — \$ 10,000

# SUBMARINE DETECTION




NCSC


# FUTURE MADOM CONCEPT



- A SENSOR TRIAD WILL PROVIDE:
- HIGH DETECTION PROBABILITY
  - LOW FALSE CONTACT RATE



NAVAL COASTAL SYSTEMS CENTER—PANAMA CITY, FLORIDA




OTHER  
MAGNETIC  
ANOMOLIES


HELICOPTER



DEWAR (IF NEEDED  
GRADIOMETER



LAND  
MINES



WASTE  
(NUCLEAR &  
OTHERWISE




UNEXPLODED  
ORDNANCE

WHAT THE USER WANTS TO DO:

FIND MAGNETIC ANOMALIES

M.A.D.  $\equiv$  MAGNETIC ANOMALY DETECTION

WHAT TO MEASURE?



1000+  
SYSTEMS IN  
USE TODAY

$|B|$

{ EASY TO MEASURE  
HARD TO INTERPRET

NONE  
IN USE  
TODAY

$\vec{B} = [B_x, B_y, B_z]$

{ IMPOSSIBLE TO  
MEASURE ON A  
MOVING PLATFORM

20 YEARS  
OF  
RESEARCH


$\frac{d\vec{B}}{d\vec{r}}$

|                   |                   |                   |
|-------------------|-------------------|-------------------|
| $\frac{dB_x}{dx}$ | $\frac{dB_y}{dx}$ | $\frac{dB_z}{dx}$ |
| $\frac{dB_x}{dy}$ | $\frac{dB_y}{dy}$ | $\frac{dB_z}{dy}$ |
| $\frac{dB_x}{dz}$ | $\frac{dB_y}{dz}$ | $\frac{dB_z}{dz}$ |

{ HARD TO  
MEASURE  
  
EASY TO  
INTERPRET



# MOTION INDUCED NOISE




WHY THE INCREASE IN NOISE  
WHEN IN MOTION?

↑  
BIG PROBLEM FACING  
THE APPLICATION

# LOW FREQUENCY NOISE ( $1/f$ ) IN A MAGNETIC FIELD:

ZERO FIELD-COOLED

IN ZERO FIELD




NO TRAPPED FLUX  $\Rightarrow$

NO EXTRA  $1/f$  NOISE

FIELD-COOLED

IN SAME FIELD




UNIFORMLY TRAP FLUX  $\Rightarrow$

A LITTLE EXTRA  $1/f$  NOISE  
(20 - 100%)

LARGE CURRENT (500 mA)

ZERO FIELD-COOLED


IN A FIELD



INJECTED TRAPPED FLUX


CIRCULATING CURRENT LOWER TRAPPING BARR & FLUX RUSHE IN.  $\Rightarrow$   
A LOT OF  $1/f$  N

# CONDUCTUS IMAG MAGNETOMETER



$$B_T \approx 1 \mu\text{T}$$

# SOURCE OF NOISE WITHOUT FLUXDAM



$$I_c \approx 4 B_A r_p / \pi \mu_0 \quad \left. \begin{array}{l} \text{CIRCULATING} \\ \text{CURRENT FROM} \\ B_A \end{array} \right\}$$

$$I_T \approx (J_c d w_s) \left[ 2.5 \left( \frac{\bar{\Phi}_0 / w_s^2}{10^{-6} J_c d} \right)^{1/4} \right] \quad \left. \begin{array}{l} \text{MAX } I_c \\ \text{BEFORE} \\ \text{FLUX} \\ \text{ENTRY} \end{array} \right\}$$






$$I_T \approx \sqrt{w_s}$$

$$B_T \approx 1 \mu T$$


DESIGN  
RULE

IF  $I_0^{F.D.} < I_T$  AVOIDS THIS PROBLEM

# HOW TO AVOID PERSISTENT CIRCULATING CURRENTS




# STEP EDGE 1x1 CM MAGNETOMETER




## IBM SQUIDS WITH FLUX DAMS:

1 x 1 cm D.C. MAGNETOMETERS



NOISE FROM CURRENTS  
AROUND THE PICKUP LOOP FILMS:

$$I_{\text{circ}} \leq I_0^{\text{F.D.}}$$



$$I_T < I_0$$

DESIGN R1

$$I^* = 4Bw_p/4\mu_0$$

$$I_T^* \approx (J_c d w_p) \left[ 2.5 \left( \frac{J_c / w_p^2}{10^6 J_c d} \right)^{1/4} \right]$$


$$B_T^* \approx 27 \mu\text{T}$$



## SOLUTIONS TO $I^*$ NOISE:

1)  $w_p$  SMALL  $\Rightarrow L_p$  BIG  $\Rightarrow$  POOR RESPONSE

2) ADD A SECOND LOOP:



"DUAL  
FLUXDAMS"


MAKE  $w_p$  SMALL SO THAT:

$$I^*_{\text{FROM EARTH FIELD}} \ll I^*_T$$

# TWO FLUXDAM SQUID MAGNETOMETER


14x14 mm substrate  
2 flux dams  
160 nm line width  
2 mm "washer" width

Lo: A/D, SQUID  
#30, SQUID





FABRICATED BY MAGNESENSORS (SAN DIEGO)  
FOR IBM  
WITH DAN LATHROP (QM)

# FOUR FLUXDAM SQUID MAGNETOMETER




FABRICATED BY MAGNESENSORS (SAN DIEGO)  
FOR IBM  
WITH DAN LATHROP (QM)



ONE WIDE PICKUP  
LOOP  $\Rightarrow 7 \text{ nT}/\bar{\Phi}_0$


ANOTHER FOUR FLUX DAM SQUID:




OPERATING WITHOUT BIAS REVERSING


BIOMAGNETISM



# THE HEART AS A PUMP
















# UNSHIELDED BIDMAGNETOMETER:





## ECONOMIC ISSUES IN SQUIDERY:

Making (just) SQUIDs is a money losing operation today.

- Compare: Conductus (SQUIDs) with Billingsley Magnetics (fluxgates)
- SQUIDs are very high tech and hard to make
- SQUIDs are a "part"
- Most SQUID markets are too small to support the research that is needed to develop the SQUID part of the solution. (-> government money)
- Need cheaper SQUID technology

Making systems that use SQUIDs can make money.

- Look at Quantum Design, biomag companies, and IBM
- The SQUID is a key part but a minor cost item in most systems.
- Cost to enter a new market is far more than that of the SQUID sensors
- Risk is very high since products are new and different.
- There are just a few cases of market pull, usually its technology push.

SQUIDs (and superconductivity) have far more intellectual (and snob) appeal than other types of magnetic sensors, i.e. Fluxgates.

## WHAT COULD CHANGE ALL THIS DOOM AND GLOOM?

(small scale) High-Tc needs to become a part of some major research and/or commercialization area (as defined by Dow Jones):

Electronics, computers, communications, and information

Aerospace and transportation

Biophysics, biochemistry, medical, and drug-related

Energy exploration, production, and distribution

Food

Entertainment

Investment, etc.


Defense

How to find a part in the mainstream?

1. Invent a room temperature superconductor.
2. Pretend we did:

Work toward the goal of a micromachined silicon-chip-based refrigerator for high-Tc low-power applications. A small DIP with only electrical power inputs that can cool a high-Tc chip to 77K.

# "SILICON MICROMACHINED REFRIGERATOR"



RADIATION LOAD  $77^{\circ} \leftarrow 300^{\circ} \text{K}$   $1 \times 1 \text{ cm}$   
 $\sim 0.1$  WATTS

CONDUCTION LOAD  $\sim 0.2$  WATTS



Y. TAVRIN & M. SIEGEL





Fig. 1. Schematic view of the measuring head of the HTS SQUID microscope showing a cut of the cryostat containing the three SQUID sensors with flux focusers forming a second order gradiometer.

HTS SQUID · MICROSCOPE  
WITH A FERROMAGNETIC FLUX FOCUSER.

# IBM X-SCANNER



1 GAUSS ON SAMPLE  $\Rightarrow$  0.002  $\Phi_0$  ON SQ

SPATIAL RESOLUTION:

EXISTING

$\sim 5 \mu\text{m}$

POSSIBLE

$\sim 0.1 \mu\text{m}$

TIP SIZE  
&  
SHAPE